




ABOVE PAR
TECH

Ag Leader RightSpot Parts

10inch spacing





ABOVE PAR
T E C H

Ag Leader RightSpot Parts
10inch spacing

ITEM	PART NUMBER	DESCRIPTION	NOTE
1	4004175-18	CABLE- GPS 6000/7000 SERIES DUAL PORT	
2	4005505-12	CABLE- INCOMMAND - AUX. SERIAL (12FT)	
2*	4005560-12	CABLE - INCOMMAND AUX SERIAL/VIDEO 2 CAMERAS (12FT)	IF CAMERAS ARE INSTALLED
3	4007697-12	CABLE - DISPLAY - INCOMMAND V2 (12FT)	7FT ALSO AVAILABLE
4	4005749	GPS RECEIVER - SMART7W	UNLOCKED FOR RTK
5	4200701	DISPLAY KIT - INCOMMAND GO 16 CELLULAR	
6	4007789-6	CABLE - POWER - INCOMMAND V2/GUIDANCE/HIGH CURRENT	12FT ALSO AVAILABLE
7	4000437	AUXILIARY INPUT MODULE	
8	4000219-1	CABLE - CAN BUS STUB - 1FT	
9	4008117-2	CABLE - L2 SWITCH INPUTS - 3 SECTION (2FT)	
10	400656-008	CABLE - GEN2 CAN A/LOCAL BREAKOUT (8IN)	
11	4006728-005	CABLE - RIGHTSPOT HUB SYNC (5IN)	
12	4003824-6	CABLE - CHANNEL (ML2M)(DT3F) 6FT	USED ON ALL HP MACHINES & SMITHCO
13	4002871	TERMINATING RECEPTACLE - LOCAL CAN	
14	4002870	TERMINATING PLUG - LOCAL CAN	
15	4006644	MODULE - L2 LIQUID RATE CONTROL	
16	4003634	PRESSURE SENSOR ASSEMBLY - 3 PIN METRIPACK, ¼ NPT, 250PSI	
17	4003610-6	CABLE - AG LEADER PRESSURE SENSOR (3-WIRE MP TOWER) 6FT	15FT ALSO AVAILABLE
18	4006655-5	CABLE - HIGH CURRENT POWER - RIGHTSPOT HUB (5FT)	12FT ALSO AVAILABLE
19	4006681-2	CABLE - RIGHTSPOT HUB - CAN INTERFACE (2FT)	
20	4200606	MODULE KIT - RIGHTSPOT HUB	
21	150004-015	CABLE - RIGHTSPOT CAN EXTENSION (15FT)	
22	150004-010	CABLE - RIGHTSPOT CAN EXTENSION (10FT)	
23	150003-005	TERMINATOR - RIGHTSPOT CAN	2 REQUIRED
24	42000607	MODULE KIT - RIGHTSPOT VALVE CONTROL	2 REQUIRED
25	118200-203	HARNESS - RIGHTSPOT 6 DROPS (10IN SPACING)	
26	116500-250	VALVE ASSEMBLY - STANDARD TEEJET	23 USED ON 20FT BOOM