




ABOVE PAR
T E C H

Parts- Switchbox

Toro5800

PART NUMBER	DECRPTION	QUANTITY	IMAGE
SWITCHBOX6-T	6 GANG SWITCHBOX-TORO	1	
EL-1020-T	SWITCHBOX HARNESS-TORO	1	
SW-3PIN	SPST SWITCH-3PIN FOR PUMP ON/OFF	1	
SW-5PIN	SPST SWITCH-5PIN FOR MASTER & SECTION COMMANDS	4	

